

AIR TO AIR HOME HEAT PUMPS SPARE PARTS

MODEL	SPARE PART NAME
DH454B-2ZC	Motor
DH454B-2ZC	Diversion ring
DH454B-2ZC	Propeller fan
DH454B-2ZC	Weatherproof cover
DH454B-2ZC	Gas Liquid separator
DH454B-2ZC	Sound insulation
DH454B-2ZC	Outdoor electrical system
DH454B-2ZC	Electrical cover
DH454B-2ZC	Base
DH454B-2ZC	Globe valve assembly
DH454B-2ZC	Four-way valve module
DH454B-2ZC	EXV
DH454B-2ZC	Compressor
DH454B-2ZC	Valve supporter
DH454B-2ZC	Front pane1
DH454B-2ZC	Front pane 2
DH454B-2ZC	Supporter
DH454B-2ZC	Condenser
DH454B-2ZC	Top cover
DH454B-2ZC	Cabinet carton
DH454B-2ZAH	Inside electrical box cover
DH454B-2ZAH	Main PCB
DH454B-2ZAH	Electrical fixing board
DH454B-2ZAH	Transformer
DH454B-2ZAH	Grounding screw
DH454B-2ZAH	wiring fixing board
DH454B-2ZAH	Air duct Fixing Plate
DH454B-2ZAH	Supporter ass'y
DH454B-2ZAH	Base ass'y
DH454B-2ZAH	Drainage pan supporter ass'y
DH454B-2ZAH	Wind turbine water baffle
DH454B-2ZAH	Filter cover

AIR TO AIR HOME HEAT PUMPS SPARE PARTS

DH454B-2ZAH	Drainage pan II
DH454B-2ZAH	Drainage pan I
DH454B-2ZAH	Drainage brace
DH454B-2ZAH	Drainage pan clap
DH454B-2ZAH	Evaporator ass'y
DH454B-2ZAH	Thermostatic expansion valve
DH454B-2ZAH	Evaporator output pipe ass'y
DH454B-2ZAH	Bolt
DH454B-2ZAH	Brushless DC motor
DH454B-2ZAH	Motor bracket I
DH454B-2ZAH	Motor bracket II
DH454B-2ZAH	Upside board ass'y
DH454B-2ZAH	Cover plate ass'y
DH454B-2ZAH	Downside board ass'y
DH454B-2ZAH	Terminal
DH454B-2ZAH	Indoor carton
DH454B-3ZAH	Inside electrical box cover
DH454B-3ZAH	Main PCB
DH454B-3ZAH	Electrical fixing board
DH454B-3ZAH	Transformer
DH454B-3ZAH	Grounding screw
DH454B-3ZAH	wiring fixing board
DH454B-3ZAH	Air duct Fixing Plate
DH454B-3ZAH	Supporter ass'y
DH454B-3ZAH	Base ass'y
DH454B-3ZAH	Drainage pan supporter ass'y
DH454B-3ZAH	Wind turbine water baffle
DH454B-3ZAH	Filter cover
DH454B-3ZAH	Drainage pan II
DH454B-3ZAH	Drainage pan I
DH454B-3ZAH	Drainage brace
DH454B-3ZAH	Drainage pan clap
DH454B-3ZAH	Evaporator ass'y
DH454B-3ZAH	Thermostatic expansion valve
DH454B-3ZAH	Evaporator output pipe ass'y
DH454B-3ZAH	Bolt

AIR TO AIR HOME HEAT PUMPS SPARE PARTS

DH454B-3ZAH	Brushless DC Motor
DH454B-3ZAH	Motor bracket I
DH454B-3ZAH	Motor bracket II
DH454B-3ZAH	Upside board ass'y
DH454B-3ZAH	Cover plate ass'y
DH454B-3ZAH	Downside board ass'y
DH454B-3ZAH	Terminal
DH454B-3ZAH	Indoor carton
DH454B-3ZC	Motor
DH454B-3ZC	Diversion ring
DH454B-3ZC	Propeller fan
DH454B-3ZC	Waterproof cover
DH454B-3ZC	Gas liquid separator
DH454B-3ZC	Sound insulation
DH454B-3ZC	Outdoor electrical system
DH454B-3ZC	Electrical cover
DH454B-3ZC	Base
DH454B-3ZC	Globe valve assembly
DH454B-3ZC	Four-way valve module
DH454B-3ZC	EXV
DH454B-3ZC	Compressor
DH454B-3ZC	Valve supporter
DH454B-3ZC	Front pane1
DH454B-3ZC	Front pane 2
DH454B-3ZC	Supporter
DH454B-3ZC	Condenser
DH454B-3ZC	Top cover
DH454B-3ZC	Cabinet Carton
DH454B-4ZAH	Inside electrical box cover
DH454B-4ZAH	Main PCB
DH454B-4ZAH	Electrical fixing board
DH454B-4ZAH	Transformer
DH454B-4ZAH	Grounding screw
DH454B-4ZAH	wiring fixing board
DH454B-4ZAH	Air duct fixing plate
DH454B-4ZAH	Supporter ass'y

AIR TO AIR HOME HEAT PUMPS SPARE PARTS

DH454B-4ZAH	Base ass'y
DH454B-4ZAH	Drainage pan supporter ass'y
DH454B-4ZAH	Filter cover
DH454B-4ZAH	Drainage pan II
DH454B-4ZAH	Drainage pan I
DH454B-4ZAH	Drainage brace
DH454B-4ZAH	Drainage pan clap
DH454B-4ZAH	Evaporator ass'y
DH454B-4ZAH	Thermostatic expansion valve
DH454B-4ZAH	Evaporator output pipe ass'y
DH454B-4ZAH	Bolt
DH454B-4ZAH	Brushless DC Motor
DH454B-4ZAH	Motor bracket I
DH454B-4ZAH	Motor bracket II
DH454B-4ZAH	Upside board ass'y
DH454B-4ZAH	Cover plate ass'y
DH454B-4ZAH	Downside board ass'y
DH454B-4ZAH	Terminal
DH454B-4ZAH	Indoor Carton
DH454B-4ZC	Motor
DH454B-4ZC	Diversion ring
DH454B-4ZC	Propeller fan
DH454B-4ZC	Weatherproof cover
DH454B-4ZC	Gas liquid separator
DH454B-4ZC	Sound insulation
DH454B-4ZC	Outdoor electrical system
DH454B-4ZC	electrical cover
DH454B-4ZC	Base
DH454B-4ZC	EXV
DH454B-4ZC	Four-way valve module
DH454B-4ZC	pression valve
DH454B-4ZC	Compressor
DH454B-4ZC	Valve supporter
DH454B-4ZC	Front pane1
DH454B-4ZC	Front pane 2
DH454B-4ZC	Supporter

AIR TO AIR HOME HEAT PUMPS SPARE PARTS

DH454B-4ZC	Condenser
DH454B-4ZC	Top cover
DH454B-4ZC	Cabinet carton
DH454B-5ZAH	Inside electrical box cover
DH454B-5ZAH	Main PCB
DH454B-5ZAH	Electrical fixing board
DH454B-5ZAH	Transformer
DH454B-5ZAH	Grounding screw
DH454B-5ZAH	wiring fixing board
DH454B-5ZAH	Air duct fixing plate
DH454B-5ZAH	Supporter ass'y
DH454B-5ZAH	Base ass'y
DH454B-5ZAH	Drainage pan supporter ass'y
DH454B-5ZAH	Filter cover
DH454B-5ZAH	Drainage pan II
DH454B-5ZAH	Drainage pan I
DH454B-5ZAH	Drainage brace
DH454B-5ZAH	Drainage pan clap
DH454B-5ZAH	Evaporator ass'y
DH454B-5ZAH	Thermostatic expansion valve
DH454B-5ZAH	Evaporator output pipe ass'y
DH454B-5ZAH	Bolt
DH454B-5ZAH	Brushless DC Motor
DH454B-5ZAH	Motor bracket I
DH454B-5ZAH	Motor bracket II
DH454B-5ZAH	Upside board ass'y
DH454B-5ZAH	Cover plate ass'y
DH454B-5ZAH	Downside board ass'y
DH454B-5ZAH	Terminal
DH454B-5ZAH	Indoor Carton
DH454B-5ZC	Motor
DH454B-5ZC	Diversion ring
DH454B-5ZC	Propeller fan
DH454B-5ZC	Weatherproof cover
DH454B-5ZC	Gas liquid separator
DH454B-5ZC	Sound insulation

AIR TO AIR HOME HEAT PUMPS SPARE PARTS

DH454B-5ZC	Outdoor electrical system
DH454B-5ZC	electrical cover
DH454B-5ZC	Base
DH454B-5ZC	EXV
DH454B-5ZC	Four-way valve module
DH454B-5ZC	Pression valve
DH454B-5ZC	Compressor
DH454B-5ZC	Valve supporter
DH454B-5ZC	Front pane 1
DH454B-5ZC	Front pane 2
DH454B-5ZC	Supporter
DH454B-5ZC	Condenser
DH454B-5ZC	Top cover
DH454B-5ZC	Cabinet carton

DH_MM1048US-EN_V01

AIR TO AIR HOME HEAT PUMPS SPARE PARTS